CAN-AC2-PCI

CAN Bus PCI Interface for Vehicle Electronics

CAN communication interfaces are an inexpensive alternative to diagnostic interfaces. CAN-AC2-PCI and Softing's standard CAN-API form a powerful hardware interface for communication tasks. Alternatively, the VCI can be operated with the D-PDU API.



CAN APIs

The CAN-API, which is standard for all CAN interfaces from Softing, provides powerful communication mechanisms for CAN applications. Local buffering and preprocessing on the VCI result in high performance and a reduction of time-critical tasks for the PC. Special automation APIs, such as CANopen and DeviceNET-API, are also available.

D-PDU API

The standardized programming interface provides applications with powerful multichannel communication mechanisms with vehicle protocols, such as Diagnostics on CAN (ISO 15765) and UDS (ISO 14229). It also allows integration into diagnostic systems in accordance with ISO 22900 (MVCI). D-PDU API is also available as an option.

Scalability

The CAN-AC2-PCI interface supports two independent CAN bus channels. By combining several CAN-AC2-PCI boards (or even other CAN/EDIC® interfaces), the number of communication channels available on the PC system can quickly be adapted to the relevant application.

Environment

The galvanic isolation of PC and vehicle interfaces enables trouble-free operation even in harsh manufacturing environments.

Jofing

AREAS OF APPLICATION

- ECU engineering
- Simulation
- Test/validation

ADVANTAGES

- Active card with its own microcontroller
- Local data buffering and preprocessing
- 2 independent CAN bus channels
- Additional CAN transceivers via piggybacks
- Galvanic isolation

Technial Data

Format	Short PCI card, 100x160mm
Power supply	5V (via PC)
Current consumption	Typ. 410 mA
Microcontroller	16-bit microcontroller Infineon C165
PC interface	PCI V2.1, 4kB DPRAM (16-bit)
Vehicle interfaces	2 x D-Sub 9-pin, CAN bus signals galvanically isolated from the PC interface
CAN	2 CAN channels in acc. with ISO 11898-2 and CAN 2.0B with 11-/29-bit identifier
	Slot per channel for optional piggyback with additional CAN bus transceiver (switchable via software)
Temperature range	Operation: 0 +55 °C, storage: -20 +70 °C
EMC conformity	Noise emission: EN 55022 Class B
	Interference immunity: EN 61000-6-2 (industrial environment)
	FCC part 15 subpart B Class B (industrial environment)
Software interface	CAN L2 API from Softing
Delivery scope	CAN-AC2-PCI
	CD with CAN-API software, manual as PDF file
System requirements	4 kB free addressable storage in the upper memory area and one free interrupt
	Operating system: Windows 7, Vista, XP

Order Numbers

CAN-AC2-PCI N	PCI bus interface card for 2 x CAN high-speed	

Supplementary Products and Services

CAN-AC2-PCI-LS	Piggyback for CAN low-speed with transceiver TJA1053 (or compatible);	
	one piggyback is required per CAN channel	
PDUAPI-EC	Upgrade D-PDU API software for EDIC and CAN hardware from Softing on data carrier	

Softing Automotive Electronics GmbH Richard-Reitzner-Allee 6 85540 Haar / Germany T +49 89 456 56-420 F +49 89 456 56-499 info.automotive@softing.com www.softing.com